

XLR to WP

TECHNICAL DATA

MCAXLRMIC-WP & MCAXLRLINE-WP

This adapter allows microphones or audio devices with standard XLR connectors to be used with the MM and WM Series watertight transmitters. A capacitor in the XLR connector blocks the DC bias voltage on the transmitter input jack from the output of the audio device being connected.



Typical MM Series miniature transmitter


These mic cable adapters patch line and mic levels signals from XLR jacks into the WP connector on the miniature transmitters.

For MIC level signals

To
MM Series
Transmitter

Sold as cable P/N **MCAXLRMIC-WP**

Note: For use with WM transmitter and mic or line level signals with menu setting on transmitter




For LINE level signals

To
MM Series
Transmitter

Sold as cable P/N **MCAXLRLINE-WP**

Note: Not for use with WM transmitter. Used for line level signals into MM transmitters.



581 Laser Road NE • Rio Rancho, NM 87124 USA • www.lectrosonics.com
(505) 892-4501 • (800) 821-1121 • fax (505) 892-6243 • sales@lectrosonics.com

2 August 2017