

# SMWB Series Belt Clips

## Stainless Steel Wire Kits

- Machined Aluminum Bracket
- Stainless Steel Spring Clip

The spring wire belt clip allows the transmitter to be worn on a belt or other wardrobe item where a low profile is required. Three models are available:

### SMWBBCUP

For single battery transmitter. The antenna points UP when the transmitter is worn on a belt.



### SMWBBCDN

For single battery transmitter. The antenna points DOWN when the transmitter is worn on a belt.



### SMDWBBC

For dual-battery transmitter. Can be used with antenna up or down.



## Spring-Loaded Metal Kits

- Machined Aluminum Bracket
- Machined Aluminum Spring-Loaded Clip

The spring-loaded machined aluminum clip has the same type of attachment collar as the wire clip, and installs in the same manner, but provides better retention than the wire clip. Three models are available:

### SMWBBCUPSL

For single battery transmitter. The antenna points UP when the transmitter is worn on a belt.



### SMWBBCDNSL

For single battery transmitter. The antenna points DOWN when the transmitter is worn on a belt.



### SMDWBBCSL

For dual-battery SM Series transmitter. Can be used with antenna up or down.



## Hardware part numbers

P/N 28832 set screw

P/N 26862 thumb screw

P/N 35856 1/16 in.  
(.0625 in.) hex key  
(allen wrench)



**Note: Installation is the same for both the wire clips and the spring-loaded clips.**



Two detents in the flat side of the housing align the belt clips. The antenna UP version is shown. Align the bracket so the retaining screw seats into the detent.



The clip can be retained with either the set screw or the thumbscrew.

**NOTE: Early single battery models did not have detents, so the bracket must be aligned manually.**

Align the screws with the detents in the back cover, and tighten them until they are snug. Do not over-tighten the screws.



On the antenna down version, make sure the bracket is positioned to allow the battery door to swing open

Spring loaded belt clip on single battery model mounted with thumbscrew



### Dual Battery Model



The housing on dual battery models is symmetrical, so the bracket can be positioned on either the top or bottom of the transmitter to orient the antenna accordingly.

Detents are provided in the back cover to align with the set screws in the belt clip.



When the bracket is mounted on this end, make sure the bracket is positioned to allow the battery door to swing open

